

FIG.1





FIG.2



,	120	142	144	
	SEARCH A	LL MY QUOTES	REQUEST NEW QUOTE	
PRODUCT CONFIGURATOR USER NAME: JOHN DOE 2/21/2001	CUSTOM	QUOTE SAVE ER NAME: NUMBER:	QUOTE SUBMIT ORDER	
CUSTOMER PROJECT 126 ~128 DETAILS SYSTEM 1 ///// 2 3	ENGINE 130 GENERATOR	DISTRIBUTION BREAKER 5	ON 132 134 122 -	7
CUSTOMER LOOKUP			REQUIRED FOR ORDER	
146 148 CUSTOMER NAME CUSTOMER NUMBER		Q L00K	160 UP	
152 BILLING INFO ADDRESS LINE 1 152 ADDRESS LINE 2 154 — CITY 156 — STATE 158 — ZIP	RMATION	— 150		
		CONTINU	162 JE	
	·			
		·		
		–136	~ 138 <u> </u>	
	PREVIEW	QUOTE SAVE	QUOTE SUBMIT ORDER	

	170
	SEARCH ALL MY QUOTES REQUEST NEW QUOTE
	136 138 140
PRODUCT CONFIGURATOR	PREVIEW QUOTE SAVE QUOTE SUBMIT ORDER
USER NAME: JOHN DOE 2/21/2001	CUSTOMER NAME:
400	QUOTE NUMBER:
CUSTOMER DETAILS SYSTEM	ENGINE 130 DISTRIBUTION 132 134 122 TENERATOR BREAKER PRICING
1 2 ///////////////////////////////////	4 5 6
PROJECT DETAILS172	☐ REQUIRED FOR ORDER
180	SHIPPING INFORMATION 174
□ PROJECT NAME □ □	ADDRESS LINE 1
182 LOCATION	ADDRESS LINE 2
184 CONTACT NAME	192 194 CITY
186 CONTACT EMAIL	196 ~ STATE
CONTACT PHONE	198 ZIP
190 CONTACT FAX	
	178
ENGINEERING FIRM ~ 176 ~ 200	216 ELECTRICAL CONTRACTOR
FIRM NAME	COMPANY NAME
ENGINEER	218 CONTRACTOR
202 CONTRACTOR OF THE PROPERTY	206 NAME
204 CITY STATE	CONTRACTOR 220 E-MAIL
208 COUNTRY	220 E-MAIL CONTRACTOR
ENGINEER	222 PHONE
210 E-MAIL	CONTRACTOR
CENGINEER 212 PHONE	224 FAX
ENGINEER	
214 FAX	
	CONTINUE 226
	136
	PREVIEW QUOTE SAVE QUOTE SUBMIT ORDER

	230	1.	42	144
PRODUCT CONFIGURATOR USER NAME: JOHN DOE 2/21/2001		136	138 SAVE QUOTE	QUEST NEW QUOTE 140 SUBMIT ORDER
CUSTOMER DETAILS SYSTEM GETAILS SYSTEM SYSTEM	ENERATOR	DISTRIB BREAKER 5	6	RED FOR ORDER
232 SYSTEM VOLTAGE 234 NUMBER OF GENERATORS 236 SIZE OF GENERATORS 238 ENCLOSUR	S SELECT	ONE V	7	
240 UL LISTEI 242 SHORT CIRCUIT RATIO	O SELECT	ONE \	7	
244 — MAIN BUS SIZ	<u> </u>		Z Z	JUE 248
			CONTI	NUL
	PREVIEW	- 136 QUOTE	138 SAVE QUOTE	140 SUBMIT ORDER

	/ 2	50	144	
	SEARC	H ALL MY QUOTES	REQUEST NEW QUOTE	
PRODUCT CONFIGURATOR USER NAME: JOHN DOE 2/21/2001	CUS	TOMER NAME: TE NUMBER:	QUOTE SUBMIT ORDER	
CUSTOMER DETAILS SYSTEM 1 2 3	ENGINE GENERAT	5	PRICING — 6	
ENGINE-GENERATOR			REQUIRED FOR ORDER	
252 —		262	•	
MAKE OF GENERATOR SELECT	ONE 🗸	PT CONFIGURAT	ION SELECT ONE 🗸	
254 GOVERNOR/LOAD SELECT	ONE 🗸	264 BREAKER TI	SELECT ONE	
VOLTAGE REGULATION SELECT	ONE 🗸	266 BREAKER T UNIT MO		
258 ALARM SHUTDOWN SELECT		BREAKER S	IZE SELECT ONE	
GROUNDING SYSTEM SELECT 260	ONE 🔼	200		
2	70 \			
MX BOOO LED ANNUNCIATOR 272	YES ▽	•	274	
SPARE INPUT NO.1 SELECT	ONE 🗸	EVENT MESSAGE		
SPARE INPUT NO.2 SELECT	ONE 🛆	EVENT MESSAGE		
SPARE INPUT NO.3 SELECT	ONE 🗸	EVENT MESSAGE		
SPARE INPUT NO.4 SELECT	ONE 🗸	EVENT MESSAGE		
		[CONTINUE 276	
	/	136	138	
PREVIEW QUOTE SAVE QUOTE SUBMIT ORDER				

FIG.7

	280	142	144
	SEARCH AL	L MY QUOTES	REQUEST NEW QUOTE
<u> </u>		136 _1	
PRODUCT CONFIGURATOR	PREVIEW		QUOTE SUBMIT ORDER
USER NAME: JOHN DOE 2/21/2001		ER NAME: NUMBER:	
			132 134 122
CUSTOMER DETAILS - SYSTEM	LINOTINE	BREAKER	PRICING
1 2 3	4	5 ///	6
DISTRIBUTION BREAKER			REQUIRED FOR ORDER
282 TRIP UNIT TYPE		7	
	· <u>-</u>	<u>`</u>	
TRIP UNIT MODEL		<u> </u>	
	<u> </u>	SELECT LOAD	N DI OCK DOLODITY
1 SELECT FRAME SIZE	SELECT ATS		BLOCK PRIORITY
2 SELECT FRAME SIZE	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
3 SELECT FRAME SIZE ▽	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
4 SELECT FRAME SIZE	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
5 SELECT FRAME SIZE	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
6 SELECT FRAME SIZE	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
7 SELECT FRAME SIZE	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
8 SELECT FRAME SIZE	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
9 SELECT FRAME SIZE ▽	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
10 SELECT FRAME SIZE	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
11 SELECT FRAME SIZE	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
12 SELECT FRAME SIZE ▽	SELECT ATS 🗸	SELECT LOAD	BLOCK PRIORITY
286	288	290	CONTINUE 292
136			
PREVIEW QUOTE SAVE QUOTE SUBMIT ORDER			